

For more information or to purchase aftercare products

www.waxisdead.com









Revolutionary ceramic coatings & exclusive aftercare products

You must register your ceramic coating within 7 days of installation www.waxisdead.com/warranty



CARE INSTRUCTIONS

Our Ceramic Coatings are designed to protect your factory clear coat, to provide a protective sacrificial layer against the elements.

To maintain your coatings durability there are a few maintenance steps that should be followed. This will ensure long lasting protection for your vehicle.

WHAT TO DO

PROFESSIONAL CAR WASH / VALETER

- √ Hand wash using Wax is Dead[®] aftercare products
- √ Touchless wash
- √ Wax is Dead® Ceramic Foam every 6 months

HOME WASH

- √ Wax is Dead® aftercare products
- √ No wax needed
- ✓ Quality Soft microfibre Wash mitt & drying towel
- ✓ Wash in shade
- ✓ Wax is Dead® ReGen Ceramic detailer
- ✓ Wax is Dead® Ceramic Foam every 6 months.

WHAT NOT TO DO

CAR WASH

- X Drive through car wash
- X Roadside car wash

HOME WASH

- X Don't wash in sun
- X Don't use abrasive polish
- X Don't use wax
- Don't use abrasive Towels
- X Don't use Harsh Chemicals

THE CURING PROCESS

Full Curing time is 4 Days depending on environmental conditions such as humidity and temperature, the car must NOT get wet in the first 24 hours of application while the coating is at its most important stage of curing.

If for any reason the vehicle gets wet in this period it can cause damage to the coating and cause water spots, and these can be expensive to remove.

The Following 2 weeks are equally important and you must avoid the following:

- Parking under a shedding tree.
- Allowing bird droppings, sap or pollen to sit on the car and bake in the sun.
- Washing

If you notice that your car gets water spots, bird droppings, tree sap etc.

During the first two weeks, immediately remove it following our care instructions.

Keep in mind the coating is soft; be gentle when working on the paint.

WASHING TIPS

Always wash your vehicle with a three bucket method using buckets with grit guards.

- 1x Bucket warm water with **WAX IS DEAD** shampoo
- 1x Bucket Rinse
- 1x Bucket for Wheels & Tyres only.

First rinse the vehicle with a hose or pressure washer, then use snow foam or soap from your wash bucket start from the top and work your way down making sure you rinse the wash mitt or sponge in the rinse bucket as you go round the vehicle.

Use another sponge or wheel brush for the wheels and tyres and the wheel bucket only.

Once vehicle is clean, finish off with **WAX IS DEAD** Ceramic Foam maintenance wash at least every 6 months.

DRYING TIPS

Always dry completely and never leave to "air" dry. Tap water contains minerals that may leave deposits creating water spots. Only use a quality microfibre drying towel for best results and avoid aggressive wiping, allowing the material to absorb the water. A touchless drying process is a great way to avoid any marking. (Air Blower)

AFTER WASHING

There is no need for waxing your vehicle as products will now not bond to the Ceramic Coating. However we have created aftercare products to work in harmony with **WAH IS DEAD*** ceramic coatings.

Ask your local installer for details as we know people enjoy cleaning and taking care of their vehicles.

ANNUAL INSPECTIONS

Annual inspections are recommended to check the durability of your coating. The installer should contact you I month before the annual original installation date to get the vehicle booked in for its maintenance wash to ensure the coating is to satisfactory standards.

PLEASE CONTACT YOUR WRH IS DEAD* INSTALLER IF YOU HAVE ANY FURTHER OUESTIONS.

